The optical module pull ring cannot be removed

Overview

When removing the fiber optical module, you need to pull out the optical fiber patch cords first, and then pull the pull handle to about 90 degrees to the optical port, and then slowly take out the fiber.

Key Takeaways

Do not force the optical module; first unplug the fiber, then carefully open the pull ring or latch before pulling the module out horizontally to avoid damage.

Step-by-

Step Guidance1. Disconnect the Fiber Jumper Before attempting to remove the module, unplug all connected optical fibers. This prevents stress on the module and avoids contamination of the optical path.

Cover the fiber ends with dust caps to protect them from dust and debris. 2.

Check the Pull Ring or Latch Most SF

P and QSFP modules have a pull ring or tab that must be flipped or pressed to release the internal locking mechanism. If the pull ring is stuck: Ensure it is fully flipped open or pressed down. If it is blocked, use a small flathead screwdriver or narrow tool to gently lift or disengage the latch without applying excessive force.

3. Pull the Module Horizontally Once the pull ring is properly released, pull the module straight out at a horizontal angle. Avoid twisting, bending, or pulling at an angle, as this can deform the host's internal locking spring or damage the module.

© 2026 ALFA PRO COMMUNICATION SYSTEMS (Pty) Ltd - All rights reserved

4. Handle Stubborn Modules If the module still cannot be removed: Double-check that the fiber is fully disconnected. Confirm that the pull ring or latch is completely disengaged.

Avoid forcing the module; repeated attempts with gentle pressure are safer than applying excessive force. 5.

After Removal

Place the removed module in an antistatic bag. Cover the optical port with a dust cap to prevent contamination. Inspect the pull ring and host port for any visible damage before reinserting a module.

6.

Safety Precautions

Always use ESD protection (wrist strap or gloves) to prevent static damage. Avoid touching the optical connectors directly. Clean fiber connectors before reconnecting to another module.

Following these steps ensures safe removal of the optical module without damaging the module or the host device. For persistent issues, consult the device manufacturer's support documentation or technical support.

Article Content

The optical module pull ring can t be pulled out

When removing the fiber optical module, you need to pull out the optical fiber patch cords first, and then pull the pull handle to about 90 degrees to the optical port, and then slowly take out the fiber.

CN217561784U

An existing optical module is provided with an unlocking assembly with a pull ring, and the unlocking assembly can be displaced relative to a shell by pulling the pull ring, so that the...

Explanation Of SFP Optical Module Plugging And Unplugging

Do not force the module out without opening the pull-tab first. Doing so may damage the module or deform the host''s internal locking spring, affecting future module insertion and unlocking.

Introduction To Two Common Unlocking Mechanisms For Optical

© 2026 ALFA PRO COMMUNICATION SYSTEMS (Pty) Ltd - All rights reserved

The core principle of the drop-down mechanism is that pulling the tab causes the triangular locking feature on the module housing to drop downward and disengage from the SFP cage, thus unlocking

How to install and remove a optical transceiver

Before pulling out the SFP module, you must eject the SFP module by pulling down on the tab. Pulling out the optical module forcibly will damage the optical module and device ports.

The basic structure of the optical module and precautions for use

When inserting the fiber optical module, close the handle ring; after inserting it, pull out the fiber optical module again to check whether it is in place. If it cannot be pulled out, it means it has been inserted

Pull ring type unlocking structure on SFP module

The utility model relates to an SFP module in the field of optical fiber communication, in particular to an unlocking structure on the SFP module. It includes a base of an SFP module, a pull

FS 800G&400G Transceiver Acceptance Testing Guide

Pull out the optical module: Gently pull out the optical module, and be careful not to apply excessive force or twist the connector. Ensure that the pulling out process is smooth and does not cause

Optical module using pull tab for unlocking

The optical module is applicable to a photoelectric module for limiting the maximum height after rotation of the pull tab (1), and is applicable to a communication device with high-density ports; a color scale

Optical module pull ring and optical module

On the one hand, this pull ring body is cyclic annular enclosed construction, and has intensity height, and non-deformable''s advantage, can guarantee that the operation of drive unlocking piece motion is

A Capella: A Unique Compilation | PDF | Wellness

This document contains a long list of words beginning with "ab-" or "ac-". It does not appear to be a coherent text, but rather a collection of unrelated terms.

Pull ring device suitable for optical module

The utility model relates to a pull ring device, in particular to a pull ring device suitable for an optical module, and belongs to the technical field of optical communication.

© 2026 ALFA PRO COMMUNICATION SYSTEMS (Pty) Ltd - All rights reserved

Optical Transceiver Module Installation And Removal Guide

Conclusion Mastering the installation and removal of optical transceiver modules is essential for maintaining a robust and efficient optical network. By following this comprehensive

SFP Optical Transceiver Tutorial on Installation, Removal and ...

How to install SFP module? How to remove SFP module? What are the precautions to use optical transceivers? This SFP guide tutorial will answer those questions on maintaining

The optical module pull ring can t be pulled out

If it cannot be pulled out, it means it has been inserted to the bottom. When removing the fiber optical module, you need to pull out the optical fiber patch cords first, and then pull the pull handle to about

A pull ring unlocking structure of an optical module

The utility model provides a pull-ring unlocking structure of an optical module, which integrates an upper cover and a sliding block into an integral structure, is quick and convenient to assemble, has good

Distinguish the wavelength by the color of the pull ring of the optical ...

10G single fiber optical module wavelength and pull ring color are 1270nm (black), 1330nm (blue), 1490nm (purple), 1550nm (yellow). The above is the whole content of the color of the

How to install and remove a optical transceiver

Pull out the pull ring of the optical module, keep the angle parallel to the port and pull out the optical module. Put the removed transceiver in an antistatic bag.

Related Video Reference

This video was associated with the source search result. Verify technical details against current product documentation and project requirements.

© 2026 ALFA PRO COMMUNICATION SYSTEMS (Pty) Ltd - All rights reserved

Contact Us

Continue your research online:

Website: https://alfa-pro.co.za
Technical inquiry: https://alfa-pro.co.za/contact.html

This document is for preliminary research. Verify specifications against current standards, product documentation and project requirements.

© 2026 ALFA PRO COMMUNICATION SYSTEMS (Pty) Ltd - All rights reserved